

A T T E N T I O N

- Operation, use, upkeep and repair, if any, of the gun are extremely easy and can be quickly learned by simply reading the following instructions.
- Gun structure , as well as the possibility to replace the few parts that may wear out , guarantee its service for many seasons. Provided you follow the few and easy upkeep directions that will take a few minutes work at the end of the season , and enable you to have a practically new gun at the beginning of the next.
- Before handling the gun, draw out the spear and shoot once in the air. This will eliminate any air left in the gun body (leaked in through rubber pores) or any water.
- When idle , always keep the gun with safety catch on and without spear, so as to remove major danger.
Keep in mind, however, that even the water jet alone, that can reach 100 kg of impact power, can be very dangerous should it hit a delicate part of the body (eyes, ears, etc.). Therefore, never throw such a water jet to anybody, not even for fun.
- The outlet of water from trigger and holes on the compressor is quite natural to gun proper operation. Anyway when you are underwater you cannot feel it.
- In addition to what specifically stated in the instructions, we would like to repeat that, during the long winter period of idleness, any water inside the gun must be fresh. To leave the gun full of salt water for some months would mean the chance to clog with saltiness all threads and thus face costly repair work.